

閃光燈

X800

適用尼康





待機時間設置

使用説明書

繁體中文

連續輕按FUNC鍵進入待機時間設置[◙], 旋轉選擇撥 盤選擇待機時間

- [四] 萬5分鐘待機時間 [四] 萬10分鐘待機時間
- 「圖〕爲30分鐘待機時間、「圖」爲1小時待機時間。 [圖] 爲2小時待機時間, [圖] 爲4小時待機時間,
- [▲図]爲不休眠狀態,

選擇後按OK鍵完成設置

從屬模式時,可設置待機時間爲1小時、2小時、4小時和不

當閃光燈進入休眠狀態, 閃光燈顯示屏會顯示[[] 圖 標,唤醒閃光燈半按相機快門或按閃光燈測試閃光鍵即

連續按FUNC鍵進入照明模式設置[■□],旋轉撥盤選擇照

標準照明模式[1],普通閃光拍攝環境下的基本照明模式; 平均照明模式[] , 圖像四周的光線衰減少於標準照明模

中央重點照明模式[ன],中央重點照明模式下,圖像中央 的指數大於標準照明模式。

- ※ 平均照明模式適用於拍攝集體照,這種情况下要求光線充足,
- ※ 中央重點照明模式適用於拍攝可忽略圖像四周光線衰減的人

LOCK

用於鎖定閃光燈的設置參數,以避免閃光參數被意外 改變。

MODE

MODE爲閃光模式鍵,用於設置閃光燈閃光模式,可分别 設置iTTL全自動閃光、手動閃光、頻閃閃光模式。 長按此鍵可恢復原廠設置。

TTL

TTL為尼康的標準i-TTL模式,在此模式中無論背景亮 度如何,均可以調節閃光燈輸出量,使主要拍攝對象 得到正確曝光。

TTL模式時可設置曝光補償,曝光補償為-3.0EV至+ 3.0EV, 以1/3檔為增量±3檔。

TTLB

TTLB為尼康的i-TTL均衡補充閃光, 在此模式中可以調 節閃光輸出量, 使主要拍攝對象和背景得到均衡曝光。 TTLB模式時可設置曝光補償,曝光補償為-3.0EV至 +3.0EV。以1/3檔為增量±3檔

警告

- 請勿置於高温中或陽光直射下的封閉空間等高温地方。 ● 請保持乾燥,勿用濕手接觸産品,亦不可將産品浸入水中 或暴露雨中, 否則導致無法正常使用
- 請勿在易燃氣體中使用,違反此警告可能引發爆炸或火災。 ● 本産品涉及電池,關於電池的使用請嚴格按照相應的操作
- 規範,否則可能導致爆炸,火災 ● 不要使元件受到强烈震動, 否則可能導致産品發生故障。
- 請不要近距離對人體的眼睛觸發閃光,否則會損傷眼睛或 **導致失明**。
- 閃光燈在連續使用後,會很燙,請勿觸摸,有灼傷的危
- 閃光燈在連續使用後,請勿馬上更換電池,小心電池可能 會很湯。
- 請勿自行拆卸或修理閃光燈,内有高壓元件,有觸電的危
- 必須使用同品牌、同類型的雷池。

● 長期不使用時、請將雷池取出。

● 切勿裝錯電池正負極, 否則將導致漏液、發熱或破裂。

閃光指數: 60 (ISO100 200mm)

自動變焦:根據拍攝的視角和圖像自動設定覆蓋範圍 手動變焦:根據相機或閃光燈設置而改變

閃光模式: iTTL/M/RPT

頻閃閃光: 1-500Hz 無綫閃光: FSK2.4GHz無綫電傳輸

光學傳輸、支持主控/從屬/S1、S2 同步模式: 高速同步、前簾同步、後簾同步、防紅眼同步

照明模式:標準、平均、中央重點

可調角度: 上/下: -7/90度 左/右: 180度/180度

手動閃光: 1/128-1/1功率 (1/3檔增量) 回電時間: 2.5秒(1/1全功率輸出)

顯 示 屏: 高分辨率點陣屏 内置電源: 4節AA碱性電池或充電電池

外部接口: 熱靴、PC端口、USB端口、外接電源口

電池壽命: 180次 (1/1閃光輸出,使用三洋Eneloop電池) 燈管書命・超長書命設計

過熱警報: 多點陣温度控制、電池燈管過熱警報

曝光補償・以1/3檔爲增量+3檔

對 焦 燈: 29個點陣式輔助對焦點

FV 鎖 定: 支持

固件更新: 支持 र्ग : 78.04mm × 60.5mm × 193mm

量: 408.7g (不含電池)

頻閃閃光模式, RPT 頻閃閃光模式可使同一畫面出現一 串連續運動的影像。在頻閃閃光模式下,可設定閃光輸 出功率, 閃光次數, 閃光頻率,

- 1、閃光燈的閃光次數指每幀照片閃光燈的閃光次數。 2、閃光燈的閃光頻率指每秒鐘閃光燈的閃光次數。
- 3、使用頻閃時設定相機的快門速度,用下面公式計算 快門速度, 然後將相機的快門速度設定為慢於由計 复所得的快門谏度,

快門速度=閃光燈的閃光次數/閃光燈的閃光頻率。 例:如果閃光燈的閃光次數為10(次),閃光燈的閃光 頻率為5(Hz)。則請將快門速度設為2秒以上,也可設

※由於頻閃快門速度較慢,建議使用三腳架以防止相機/閃光

※使用頻閃時, 閃光輸出量的設定範圍為M 1/8至M 1/128。

手動閃光模式,可設置1/128至1/1全輸出間以1/3檔爲增 量設定閃光輸出功率。

設置閃光輸出功率時必須配合撥盤使用, 向左旋轉爲减 量設置,向右旋轉爲增量設置。

用於固件升級; 最新固件可在官網下載更新。 官網: www.pixelhk.com.cn

用於同步連接綫連接相機或觸發器觸發閃光。

PUSH反射鎖定釋放按鈕

按此按鈕, 閃光燈燈頭可以上下左右旋轉, 上下旋轉-7至90度、左/右旋轉180度。

使用反射板拍攝可以使人的表情中反射光綫并創建更加生 動的表情。

使用時,將反射板和廣角散光板一起拉出,推回廣角散光 板即可使用反射板。

廣角散光板

使用廣角散光板拍攝時, 閃光覆蓋範圍會擴大。使用時, 將反射板和廣角散光板一起拉出, 推回反射板即可使用廣 角散光板。

無綫閃光控制

部件名稱

-/+功能鍵

00-00

*CLS無線 閃光功能鍵

関 半 模 式 鍵

閃光燈就绪指示機

固定座鎖定杆

電池食蓋-

測試閃光按鍵 唤醒休眠按鍵

鎖定釋放按鈕

X800N PRO具有光傳輸閃光控制和無綫電閃光控制功能。 [22] 光傳輸模式;

固定座

[圖] FSK2.4GHz無綫電傳輸模式。

無綫閃光控制(光學傳輸)

X800N閃光燈具有光學傳輸閃光控制功能。安裝在相機端 的閃光燈可通過光學脉衝傳輸信號遠程控制閃光燈閃光。使 用光傳輸閃光模式時,安裝在相機端的閃光燈必須設置爲 主控模式, 遠程閃光燈設置爲從屬模式。光傳輸閃光是通 過光學脉衝實現的, 而不是無綫電信號傳輸, 傳輸距離較 小。使用時. 請注意以下問題.

- 1、在使用光傳輸閃光模式時,必須確保從屬閃光燈在有 效的控制節圍之内:
- 2、從屬閃光燈接收信號傳感器必須朝向主控閃光燈:
- 3、必須使用具有光學傳輸無綫拍攝功能的閃光燈: 4、使用光傳輸閃光模式時,主控閃光燈與從屬閃光燈之
- 間請勿放置任何障礙物,否則會影響光學信號傳輸:
- 5、在無線閃光模式下, RPT頻閃閃光只支持防紅眼同步和 前簾同步

光傳輸閃光功能參數

傳輸方式: 光學脉衝 控制模式: 主控/從屬, S1/S2

控制組别: 3組(A/B/C) 傳輸距離: 約0.7-10米

水平方向: ±40°; 垂直±30°(面向主控燈)

同步模式: 高速同步、前簾同步、後簾同步、防紅眼同步 閃光模式: TTL/M/RPT

光傳輸閃光控制操作介紹

第一次長按*CLS鍵進入無線閃光主控模式 第二次長按該鍵進入無線閃光從屬模式(SL) 第三次長按該鍵退出無線閃光模式 無線主控閃光模式可設置閃光頻道、主控閃光開關及從 屬各組別閃光模式

1、無線閃光模式選擇

進入無線閃光主控模式后,輕按SET*CLS鍵,旋轉 撥盤,選擇光傳輸模式[☑]

2、無線閃光頻道設置

進入無線閃光主控模式后,連續按SET CLS鍵,旋轉

撥盤,可設置閃光頻道[CH1],共4個閃光頻道 [CH1-CH4]。從屬閃光頻道需進入從屬界面設置。 如果主控閃光燈與從屬閃光燈頻道不同。從屬閃光燈 將不會閃光,必須將兩者設置為同一頻道。

RPT A 2008 50 mm

3、主控閃光燈開/關設置

主功能顯示界面

閃光昏闊光補償.

±3.0EU

閃光燈燈頭 向上/向下圖標

向上: 🏭

向下: 鹽屋

待機時間

*CLS功能圖標

1/128-1/1

頻閃頻率

反射角度指數

程放按鈕

液晶顯示屏

ZOOM變焦鎖

雷源盟關

彈擇撥般

反射板

廣角散光板

閃光燈頭

光學傳輸咸廠器

卜部電源插座

- 電子觸點

- 防塵、防水滴釋放裝置

-FUNC功能選擇鍵

PUSH反射鎖定

變焦模式:

TTLB Aznon 50mm

相機曝光補償

FP高速同步圖標

TTLB Azoon 50mm

0.0EU⊈ 0.0EU©

-/+鍵圖標 ZOOM變焦圖標 FUNC功能圖標

焦距: 20m-200m

進入無線閃光主控模式后,連讀按SET *CLS鍵進入主 控閃光燈開/關設置處[🖭],轉動撥盤選擇主控閃光 打開[圖]或關閉[圖] 閃光開關打開,主控閃光燈參與曝光; 閃光開關關閉, 主控閃光燈不參與曝光

※從屬模式時不可以設置閃光開或關,程序默認為打開。 ※當使用光傳輸功能時,主控閃光燈設置為關閉時,根據光學 脉衝傳輸原理,在低速同步時主控閃光燈可能參與曝光。

4、從屬燈各組別閃光模式設置

進入無線閃光模式后,連續按SET*CLS鍵,進入組別設 置處[ABC],轉動撥盤,配合SET*CLS鍵,可分別設置 A、B、C各組別的閃光模式和閃光開闢,按-/+鍵設置主 控/從屬燈的輸出功率和曝光補償。

主控閃光模式設置

在無線主控模式下, 按MODE鍵可直接設置主控閃光燈的 閃光模式, TTL、M、RPT。

- 1、在無線模式下,如需更大的閃光輸出,可增加從屬各 組別閃光燈數量,各組別的閃光燈數量無限制。 2、在無線閃光RPT模式下, 閃光頻率可設置1-100Hz, 閃
- 光功率1/8至1/128。

無線從屬模式設置

在無線從屬模式下,可設置閃光頻道、從屬組別、S1/S2 從屬燈的閃光模式和輸出功率直接由主控燈控制,按

MODE鍵, 界面顯示MODE CLS 為從屬模式。設置為從 屬模式時,閃光燈AF對焦輔助燈會3秒閃一次。

S1/S2模式

S1普通光傳輸模式: 當閃光燈設置為該模式時, 它能與 主控閃光燈的第一次閃光同步, 主控閃光燈應設置為手 動M模式,而不能使用TTL或RPT模式引閃。

S2 TTL光傳輸模式: 當閃光燈設置為該模式時, 它能與 主控閃光燈的TTL模式閃光同步,主控閃光燈需設置為 TTL模式,而不能使用手動M模式或頻閃RPT模式。 在無線從屬模式(SL)下,按MODE鍵可設置S1、S2模式, 按-/+鍵可設置S1/S2的輸出功率。

※S1/S2模式必須在光傳輸從屬模式設置,如果是無綫電 FSK2.4GHz時不能設置S1/S2模式。

還可以通過USB接口升級固件。

按鍵及功能描述

無線主控顯示界面

無緣閃光模式

ZZZ Tarif

主控閃光開/關:

主控組別.

從屬顯示界面

SL

無綫閃光模式

ZZ Tuti

F B C

功能簡介

電量信息

按鍵聲音

4

液晶屏 照明時間

-00

•€@ •€@

AF輔助對 焦燈開關

昭阳横式.

X800N PRO閃光燈具有FSK2.4GHz無綫電傳輸閃光功 能,使用無綫電傳輸閃光受壞境影響較小,傳輸和控制效率 較高。使用時必須選擇與X800N閃光燈無綫閃光相匹配的產 品. 如選擇品色KING PRO引閃器配合使用,或X800N燈與 燈之間(主控/從屬)都可以無綫電傳輸閃光。

無綫電閃光功能參數

傳輸方式: FSK2.4GHz 控制模式: 主控/從屬 控制頻道: 1-15個 控制組别: 3個(A/B/C)

傳輸距離: 約50米 閃光模式:TTL/M/RPT

同步模式: 高速同步、前簾同步、後簾同步、防紅眼同步

無綫電閃光控制操作介紹

第一次長按*CLS鍵進入無線閃光主控模式 第二次長按該鍵進入無線閃光從屬模式(SL)

第三次長按該鍵退出無線閃光模式 無線主控閃光模式可設置閃光頻道、主控閃光開關及從 屬燈各組別閃光模式。

1、無線閃光模式選擇

進入無線閃光主控模式后,輕按SET*CLS鍵,旋轉 撥盤,選擇無綫電閃光模式[📶]

2、無線閃光頻道設置

進入無線閃光主控模式后,輕按SET*CLS鍵,旋轉 撥盤,可設置閃光頻道[CH1],共15個閃光頻道 [CH1-CH15]。從屬閃光頻道需進入從屬界面設置。 如果主控閃光燈與從屬閃光燈頻道不同,從屬閃光燈 將不會閃光,必須將兩者設置為同一頻道。

3、主控閃光燈開/關設置 進入無線閃光主控模式后,連讀按SET*CLS鍵進入主

控閃光燈開/關設置處[🔤],轉動撥盤選擇主控閃光

4、從屬燈各組別閃光模式設置

進入無線閃光模式后,連續按SET*CLS鍵,進入組別設 置處[ABC],轉動撥盤,配合SET*CLS鍵,可分別設置 A、B、C各組別的閃光模式和閃光開關,按-/+鍵設置主 控/從屬燈的輸出功率和曝光補償。

主控閃光模式設置

在無線主控模式下, 按MODE鍵可直接設置主控閃光燈的 閃光模式, TTL、M、RPT。

長按此鍵進入無線控制模式,第一次長按進入無線主控 閃光模式; 第二次長按長按進入從屬模式, 再次長按退 出無線閃光模式

SET*CLS: 在無線模式下, 輕按該按鍵可設置無線閃光功能, 長按進入下一個功能。

帶*功能鍵表示可長按進入相應的功能設置。

按此設置鍵用於調整閃光燈的閃光輸出參數。

控制頻道:

主控閃光模式

從屬閃光模式

₩ OFF

從壓組別

從屬模式:

\$2

TTL A 200n 50 m

1111)

MTTL:0.0EU AM:1/32 BTTL:0.0EU CM:1/32

SLAUE A

HODE S1

1/32

\$1/\$2輸出功率:

1/128-1/1

品色 X800N PRO (專業版)是一款高性能的閃光燈。

閃光燈指數高達 GN60、體積小巧、閃光精準; X800N

PRO 内置FSK2.4GHz無綫閃光控制系統,可兼容品色

KING PRO 直接控制;全功率輸出回電小于2.5秒,可

兼容所有的尼康單反相機;采用省電設計,全功率輸出

可閃180次; X800N PRO自創多點陣温控設計, 保證不

發生過熱失控或燒壞燈頭元器件問題;外觀精致,使用

高分辨率點陣屏, 功能設計一目了然, 操作簡單明了;

此選擇撥盤可以左右旋轉調整閃光燈的設置參數, 向左

旋轉爲減少設置參數,向右旋轉爲增加設置參數。

ZOOM變焦鍵用於設置變焦模式。變焦模式分别爲手動變 焦[Mzoom]和自動變焦[Azoom],此功能設置時配合選擇

※焦距可設置20-200mm, 部份相機不支持較高的焦距, 焦距設 置應以相機爲準。20-200mm會正常顯示,超出此範圍可能顯 示出錯,與閃光燈不符的焦段也可能會顯示出錯。

FUNC功能設置

FUNC功能鍵可分別設置按鍵聲音、液晶屏照明時間、AF 對焦輔助燈、待機時間、照明模式等功能。 顯示屏功能排列項順序為: 按鍵聲音[⑩]→液晶屏照明 時間[圖]→AF對焦輔助燈[圓]→待機時間[圖]→照明模

按鍵聲音設置

輕按FUNC鍵進入按鍵聲音設置后,旋轉選擇撥盤。選擇 打開聲音[1] 或關閉聲音[1],按OK鍵完成設置。

液晶屏照明設置

連續按FUNC鍵,進入液晶屏照明時間設置[■],旋轉 撥盤選擇液品屏昭明時間。 「」爲液晶屏照明常亮.

「壓」 爲液晶照明燈亮5秒 [■1] 爲液晶照明燈亮10秒, 「◎◎〕爲關閉液晶屏照明時間. 選擇後按OK鍵完成設置。

AF 對焦輔助燈設置

對焦輔助燈主要用於拍攝環境較暗或對比度較低條件下. 此環境拍攝時打開AF, 閃光燈内置的對焦輔助燈會亮起 來輔助自動對焦

連續按FUNC鍵,進入AF對焦輔助燈設置[II],旋轉選 擇撥盤選擇打開AF[【 □]或關閉AF[【 □],選擇后按OK 鍵完成設置。

1、在無線模式下,如需更大的閃光輸出,可增加從屬各組別 閃光燈數量,各組別的閃光燈數量無限制。 2、在無線閃光RPT模式下,閃光頻率可設置1-100Hz,閃光

功率1/8至1/128。 無線從屬模式設置

在無線從屬[SL]模式下,可設置閃光頻道、從屬組別 。從屬 燈的閃光模式和輸出功率直接由主控燈控制。設置為從屬模 式時, 閃光燈AF對焦輔助燈會3秒閃一次。

WARNING: MOTOR ERROR 馬達故障、電池、燈頭過熱提示 WARNING: MOTOR ERROR BAT LAMP

馬達故障、燈頭過熱提示

WARNING: LAMP TEMPERATURE

未知錯誤提示 WARNING: ERROR 90

動恢復,恢復後,提示信息會消失,可正常使用。如果無法自 動恢復建議與經銷商聯系維修。

頻繁使用時燈頭、電池過熱保護會被激活,激活後顯示屏會出 現過熱提示,會限制閃光或停止閃光,這時請立即關閉閃光 燈,冷却後再使用,冷却後過熱保護信息會消失,消失後可正

壹年保修,從購買之日起,詳情請與工廠或經銷商聯系。

何疑問可與當地經銷聯系或登陸 http://:www.pixelhk.com.cn。

制 造 商:深圳市品色科技有限公司

址:深圳市龙华新区龙华人民路美丽AAA大厦1411 话:400-8084899

PXL F PSM151232 V10.02

當閃光燈出現故障或過熱保護被激活,顯示屏會顯示以

馬達故障提示

TEMPERATURE

WARNING: MOTOR ERROR LAMP TEMPERATURE 燈頭過熱提示

電池過熱提示: WARNING: BATTER TEMPERATURE

※ 當閃光燈馬達、未知錯誤出現提示時, 建議反復開關機嘗試自

感謝您購買品色公司產品并閱讀本説明書, 如有任

本説明書中的信息更新至2017年06月13日,如果要 與此日期之後發布的產品組合使用,有關信息請向品色經 銷商咨詢。

RoHSF@@@G(E



X800 Speedlite

For Nikon





IIIumination Mode Setting

Continuously press FUNC button to enter Illumination Mode Setting [] , the and then turn dial selector to select Illumination.

Standard Illumination Mode[📧], the basic illumination mode for

Evenness Illumination Mode is suitable for group photographs, in which sufficient light is required without light falloff at the edges.
 Center-weighted Illumination Mode is suitable for portraits, in which the light falloff at the edge of an image can be ignored.

It's applied to lock the parameter settings of the flash, avoiding the flash parameter may be changed accidently.

MODE

Flash mode button. It's applied to set the flash mode. You can set the flash mode to i-TTL full auto flash, Manual flash and RPT flash mode individually.

Press and hold this button to reset your flash to the original factory

settings.

TTL

TTL is Nikon standard i-TTL mode. Under this mode, the flash output level is adjusted regardless of background brightness, making the main shooting subject get correct exposure. Under TTL mode, the EV (Exposure Compensation Value) can be set in 1/3 EV steps from -3.0 EV to +3.0 EV.

TTLB

TTLB is Nikon i-TTL balanced fill-flash. Under this mode, the flash output level is adjusted, making the main shooting subject and background get balanced exposure. Under TTLB mode, the EV (Exposure Compensation Value) can be set in 1/3 EV steps from -3.0 EV to +3.0 EV.

RPT

RPT Flash Mode. RPT flash mode can make one image displays as a serial continuous moving image. Under RPT flash mode, you can set flash output power, flash times and flash frequency.

1. The number of flash firing is the number of times the flash fires per

2. The frequency of flash firing is the number of times the flash fires per

second.

3.Set cameras shutter speed when using RPT mode. Calculate the shutter speed by using following formula, and then set camera shutter speed less than that of calculated by the formula.

Shutter speed= the number of flash firing/ the frequency of flash firing. For example, if the number of flash firing is 10(times), the frequency of flash firing is 5(Hz). Then set the shutter speed over 2 second. You may also set Bulb mode.

- 6 -

Warning

- Do not expose this product in high temperature location or confined
- spaces exposed to strong direct sunlight and other overheating places Keep it dry. Do not touch this product with wet hand. Do not expose this
- product to water or rain, or you may not be able to use it. Do not use it in inflammable gas, or it may cause explosion or fire.
- ●This product involved in battery. Please strictly follow the corresponding operations related to battery, or it may cause explosion or fire.
- Do not put the component in strong vibration, or it may cause fault of this product.
- Remove the batteries during long periods of non-use
- Do not use the flash light in a short distance from the eyes, or it may cause possible injury to eyes or blindness.
- After continuous use, it will be very hot. Do not touch, or it may cause burn • After continuous use, the battery might be hot. Please be careful when changing new battery.
- ●Do not disassemble or maintain this product by yourself. The internal high voltage will cause electric shock.
- Only the same brand and battery type can be used.
- Make sure the batteries are installed correctly, or it may lead to leak.

Specifications

60 (ISO100 200mm) GN: Flash coverage Range: 20 -200mm According to shooting angle and image to Auto ZOOM: auto adjust the coverage range According to camera or flash setting to adjust the zoom range Manual 700M: Flash Mode: Stroboscopic Flash: 1-500Hz FSK 2.4GHZ radio transmission/optical transmission, supports Master/Slave, S1/S2 Wireless Flash:

High Speed Sync, 1st Curtain Sync, 2nd Curtain Sync, Red-eye Reduction Sync SYNC Mode: Illumination Mode: Standard, Evenness, Center-weighted Up/down:-7/90 degree Left/Right:180 degree/180 degre Adjustable Angle:

Manual Flash 1/128-1/1 output control (1/3rd increments) Less than 2.5 sec (1/1 full power output) Recycle Time: LCD Display Screen: High definition dot matrix screen 4×AA size alkaline batteries or rechargeable batteries Internal Power Source:

Hot shoe, PC port, USB port, external External Interface: EV: In 1/3rd increments (±3 stops) 180 times(1/1 flash output, with Sanyo Battery Life Eneloop batteries) Flash Tube: Ultra-long battery life design Multi dot matrix temperature control, battery and flash tube overheating warning Overheating Warning:

29 point assist focus point AF-Assist Beam FV Lock: Support Firmware Upgrade

78 04mm×60.50mm×193.00mm Dimension: Weight: 408.7g (excluding batteries)

X Since low shutter speed is used under RPT mode, use of a tripod is recommended to prevent camera/ speedlite from shaking. *** Under RPT mode, flash output level can be set between M 1/8 to

M

Manual Flash Mode. You can set the flash output from 1/128 power to 1/1 full output in 1/3 increments

Set flash output power with dial selector. Turn left to reduce setting parameter, and turn right to increase setting parameter,

USB Port

English

It's applied to upgrade the firmware. You can download the newest firmware from PIXEL website www.pixelhk.com.

It's applied to connect camera with SYNC cable or trigger flash.

PUSH Reflect Lock Release Button

By pressing this button, the flash head can be adjusted to up/down and left/right. Up/down ward angle-7 to 90 degree, left/right angle 180 degree.

Reflector

Using the reflector enables you to reflect light in a person's eyes

and create a more vivid expression. When using, pull out the reflector and wide panel together, and push back the wide panel. Then you may use the reflector.

Using wide panel, flash coverage range will enlarge When using, pull out the reflector with wide panel together and push back reflector. then you may use the wide panel

Wireless Flash Control

X800N PRO supports optical transmission and radio transmission

Wireless Flash Control(Optical Transmission)

Optical transmission mode;

[Image: PSK 2.4GHz radio transmission mode.

trol function. The speedlite mounted on the camera can transmit signal via optical pulse to control firing remotely. When using wireless flash mode, the speedlite mounted on the camera should set as Master mode, and the off-camera flash set as Slave mode. Optical transmission flash is achieved by optical pulse, not wireless radio signal transmission so the transmission distance is very short. Please note the following

Make sure the slave unit within effective control range when using optical transmission flash mode; The receiving signal sensor of slave unit should face to master unit; You are required to use flashes that are equipped with an optical

Mounting Foot

transmission shooting function;

4. Please do not place any obstacles between the master unit and salve unit when using optical transmission flash mode, or it may affect optical signal transmission;

5. Under wireless flash mode, RPT firing only supports Red-eye

Reduction and 1st curtain sync functi

Optical Transmission Flash Function Parameter

Transmission Method: Optical puls Transmission Method: Optical pulse Mode Control: Master/Slave, S1/S2 Channel Control: 1-4 channels Group Control: 3 groups(A/B/C) Transmission Distance: about 0.7-10m Flash Ratio Control: 8:1-1:1-1:8
Sync Mode: HSS, 1st curtain sync, 2nd curtain curtain sync, Red-eye Reduction sync Flash Mode: TTI /M/RPT

Optical Transmission Flash Control Operation Introduction

Hold and press*CLS button to enter wireless flash Master mode Hold and press this button again to enter wireless Slave mode(SL)
Hold and press this button once again to exit wireless flash mode
Under wireless Master flash mode, you can set flash channel, Master
flash ON/OFF and flash mode for every group of Slave units.

1. Wireless Flash Mode Select

After entered wireless flash Master mode, gently press SET*CLS button and then turn dial selector to select optical transr

2. Wireless Flash Channel Setting

After entered wireless Master flash mode, continuously press SET*CLS button and then turn the dial selector to set flash channel [CH1]. In total, 4 flash channels [CH1-CH4] for options. Slave flash channel need to set in the Slave interface. If the transmission channels of the Master unit and Slave unit are different, then the Slave unit doesn't fire. Master and Slave unit must be set to

3. Master Flash ON/OFF Setting

After entered wireless Master flash mode, continuously press SET*CLS button to enter Master Flash ON/OFF [] , then turn dial selector to select Master Flash ON [] or OFF [] When flash is ON, Master flash will join in exposure. When flash is OFF, Master flash will not join in exposure.

Inder Slave mode, it's not available to set flash ON/OFF. Here It's DN by default ON by default.
When using optical transmission function and the Master flash set
as OFF, the Master flash may join in exposure under low sync
speed according to optical pulse transmission theory.

4. Flash Mode Setting for Every Group of Slave Units After entered wireless flash mode, continuously pre

button, and then move setting icon to Group Setting [ABC], then turn the dial selector. Use with SET*CLS button to set the flash mode and flash ON/OFF for every group individually. Press -/+ button to set the output power and exposure compensation of Master/Slave units.

Wireless Flash Mode Setting

Main Function Interface

ZOOM Mode

Mzoom

Azoom

ŤTLBÁzza SÖn

→0.0EV耳 0.0EVロ

FP HSS Icon

TTLB A 2008 50m

0.0EV□ 0.0EV©

-/+Button Icon ZOOM Icon FUNC Function Icon

RPT A 200m 50m v IIII

Focal Distance

Battery Info

Buzzer

©[20

LCD Lighting

00

0.5

(II)

O(m

-(€)

) =[0]

Function Setting

RPT Times

Flash Mod TTL

±3.0EU

Flash Head Up

UP· EE

Down:

Stand-hy

*CLS Function Icon

Outnut Power

1/128-1/1

RPT Frequency

ZOOM Buttor

FUNC Function Select Button

- Confirm Setting Buttor

Reflector

Wide Panel

Optical Transmission

USB Port

Contacts

<OFF> Power OF <ON> Power ON <LOCK> Button

Dial Selector

- Dust and Water-resistan

0000

Flash Mode Butto

Mounting Foot Lock

AF-assist Beam

Lock-release Switch-

Under wireless Master mode, press MODE button to set the flash mode of Master unit as TTL, M and RPT directly.

1. Under wireless mode, if need more flash output, you can invite the numbers of the salve unit which is unlimited.

-3-

2. Under wireless flash RPT mode, the flash frequency can be set as 1-100Hz, and the flash power as 1/8 to 1/128

Wireless Slave Mode Setting

Under wireless slave mode, you can set flash channel, Slave group,

Under wireless slave mode, you can set liast channel, clave group, and \$1/\$2 mode.

The flash mode and output power of Slave unit is controlled by Master unit directly. Press MODE button, the interface will display MODE CLS as Slave mode. Under Slave mode, the AF-assist beam will blink every 3 second.

S1/S2 Mode

S1 Manual Optical Control Mode: when set flash as this mode, it can work with the first firing of the Master flash synchronously. Set Master flash as manual M mode. Here TTL or RPT mode.

S2 TTL Optical Control Mode: when set flash as this mode, it can work the TTL mode of the Master flash synchronously. Set Master flash as TTL mode. The M or RPT mode cannot be fired.

Under wireless Slave (SL) mode, press MODE button to set S1/S2 mode. Press -/+ button to set the output power of S1/S2.

* \$1/\$2 mode must be set under optical transmission Slave mode. If under radio FSK 2.4GHz mode, then you can't set \$1/\$2 mode.

Radio Flash Control

X800N PRO speedlite is equipped with FSK 2.4GHz radio transmission wireless flash shooting function. With radio transmission, flash firing is less affected by obstacles, so its transmission and control efficiency are much higher. When using with PIXEL king PRO/Nikon together, or among X800N PRO speedlites (Master/Slave), you can use wireless radio


Radio Transmission Flash Function Parameter

Transmission Method: FSK2.4GHz Iransmission Method: FSK2.4GHz Mode Control: Master/Slave Channel Control: 1-15 channels Group Control: 3 groups (A/B/C) Transmission Distance: about 50M Flash Mode: TTL/M/RPT Sync Mode: HSS, 1st curtain sync, 2st curtain sync, and Red-eve Reduct rnc Mode: FTE/M/RP1 rnc Mode: HSS, 1st curtain sync, t curtain sync and Red-eye Reduction Sync

Radio Flash Control Operation Introduction

Hold and press*CLS button to enter wireless flash Master mode Hold and press this button again to enter wireless Slave mode(SL) Hold and press this button once again to exit wireless flash mode Under wireless Master flash mode, you can set flash channel, Master flash ON/OFF and flash mode for every group of Slave units.

Wireless Master Interface



PIXEL X800N PRO(PRO version) is a high-performance speedlite featuring powerful flash GN60, small and exquisite and accurate firing; it has a built-in FSK2.4GHz wireless flash control system. It's compatible with the Pixel King PRO/Nikon by direct control; the recycle time is less than 2.5sec in full power output. It's compatible with all of Nikon DSLR cameras; due to the energy-saving design, it can fire 180 times in full power output; X800N PRO has invented multi-dox matrix temperature control design which can ensure no overheating or malfunction; it enjoys control design which can ensure no overheating or malfunction; it enjoys exquisite external appearance, high definition dot matrix screen, concise function interface design, and easy and simple to handle; user can also upgrade firmware via USB port.

Button Function Introduction

mode [📶].

This dial selector is applied to adjust setting parameter of the flash. Turn left to reduce setting parameter, and turn right to increase setting

*CLS Function Button

and slave must be set to the same channe

Master Flash Mode Setting

Wireless Slave Mode Setting

Error Warinig Prompt

Motor Error Prompt WARNING: MOTOR ERROR

screen:

When flash is ON. Master flash will join in expo When flash is OFF. Master flash will not join in exposure

4. Flash Mode Setting for Every Group of Slave Units

Press and hold this button to enter wireless control mode. Press and hold this button to enter wireless flash Master mode; and then press and hold this button again to enter Slave mode; and press and hold this button once again to exit wireless flash mode.

Wireless Flash Mode Select
 After entered wireless flash Master mode, gently press SET*CLS button and then turn the dial selector to select radio flash

2. Flash Flash Channel Setting
After entered wireless flash Master mode, gently press SET*CLS button and then turn the dial selector to set flash channel [CH1, 15 flash channles [CH1-CH15] for options in total. Slave flash channel need to set in the Slave interface. If the transmission channels of the Master unit and Slave unit are different, then the slave unit won't fire. Both Master and slave must be set to the same channel.

3. Master Flash ON/OFF Setting
After entered wireless flash Master mode, continuously press
SET*CLS button, and then move setting icon to Master Flash ON/OFF [],
then turn dial selector to select Master Flash ON [] or OFF [].

4. Flash Mode Setting for Every Group of Slave Units
After entered wireless flash mode, continuously press SET*CLS
button, and then move setting icon to Group Setting [ABC], then turn
the dial selector. Use with SET*CLS button to set the flash mode and
flash ON/OFF for every group individually. Press -/+ button to set the
output power and exposure compensation of Master/Slave units.

Under wireless Master mode, press MODE button to set Master unit

1. Under wireless mode, if need more flash output, you can invite the numbers of the Slave units which is unlimited.
2. Under wireless flash RPT mode, the flash frequency can set as 1100Hz, and flash power as 1/8-1-128.

Under wireless Slave [SL] mode, you can set flash channel and Slave groups. The flash mode and output power of Slave units can be controlled directly by Master unit. If set as Slave mode, the flash AF- assist beam will blink for every 3 sec.

When an error occurs on the flash or overheating protection

Motor Error, Battery and Flash Head Overheating Prompt: WARNING: MOTOR ERROR BAT LAMP TEMPERATURE

Motor Error, Flash Head Overheating Prompt:

Flash Head Overheating Prompt

WARNING: LAMP TEMPERATURE

WARNING: MOTOR ERROR LAMP TEMPERATURE

is activated, the following information is display on the

Battery Overheating Prompt: WARNING: BATTER TEMPERATURE

and non-sleep mode

wake-up the flash.

Unknown Error Prompt WARNING: ERROR 90

> When a prompt occurs on flash motor and unknown error, you are advised to switch on-off the flash repeatedly to make it self-recovery. After recovery, the prompt info will disappear, and you can reuse it. If not, you are advised to contact the dealer for

SET*CLS: under wireless mode, gently press this button to set

wireless flash function. Hold and press again to enter next function With*asterisk function button means press and hold this button to enter the

This function button is applied to adjust flash output power paramete

This Zoom button is applied to set Zoom mode, divided into manual

zoom[M_{200m}]and auto zoom[A_{200m}]. Set this function with dial

※ Focal distance can set as 20-200mm. Some cameras do not support higher focal distance. The setting of focal distance is subject to camera. In a range of 20-200mm, it will be displayed correctly. But an error may occur if out of this range, or the range doesn't conform to this flash.

The FUNC Function can set Buzzer, LCD Back Light Time, AF-assist

The sort order of the LCD function is : Buzzer[□ □ 1→LCD Back-

Gently press FUNC button to enter Buzzer setting and then turn dial

Continuously press FUNC button to enter LCD Illumination Time Setting[58], and then turn dial selector to select LCD Illumination Time.

AF-assist beam is mainly applied to low-light or low contrast shooting avironment. Under this condition, the built-in AF-assist beam activates

[]. Turn dial selector to select AF ON [] or AF OFF[] and

| Impease the stand-by time; | Impease the stand-by time the setting. | Impease the stand-by time as 1 hrs., 2 hrs., 4 hrs.

When flash entered sleep mode, the flash display screen will show

] icon. Half-press camera shutter or press Flash Test Button to

Continuously press FUNC button to enter AF-assist beam setting

Continuously press FUNC button to enter stand-by time setting. Turn

ctor. Select to Buzzer ON[🚳]or OFF[🚳], press OK button to

beam. Stand-by Time and Illumination Mode function individually

corresponding function setting.

FUNC Function Setting

LCD Illumination Time Setting

Illumination Model FR 1

Buzzer Setting

onfirm the setting.

[a] means on all the time;

1 means on for 10 sec:

1 means turn off the light

AF-assist Beam Setting

automatically to help autofocus

then press OK to confirm setting.

dial selector to select stand-by time.

🕼 1 means 5mins stand-by time:

I means 10mins stand-by time

1 means 1hr stand-by time

1 means 30mins stand-by time

Stand-by Time Setting

1 means on for 5 sec:

-/+ Setting Button

ZOOM

When you use the flash continually, flash head and battery overheating protection will be activated, then the LCD display screen will shows error prompt and restrict flash firing. Now please turn off the flash and allow a rest time for reuse. Then the prompt info will disappear, and you can reuse it.

Warranty

One year warranty from the day of purchase. Please kindly contact PIXEL or distributor for more details.

Thank you for using PIXEL product and read this instruction manual. If you have any questions, please contact your local dealer or visit http://www.pixelhk.com

The instruction manual is updated on June. 13,2017 For information on the compatibility with accessories marketed after this date, please contact PIXEL's dealer for advice.

- 11-



_ 7 _ _ 9 _ **–** 8 **–** - 10-